

# XPress Ethernet Bridge

## **USER'S MANUAL**



#### XPress Ethernet Bridge User's Manual

Thank you for your purchase of the XPress Ethernet Bridge.

If you have any questions when configuring your Digi system, the best place to get answers is to visit http://www.digi.com/products/wireless/xpress.jsp. You will also find the latest updates there. If more assistance is needed, send email to rf-experts@digi.com or call technical support at the number below during normal business hours.

## **Technical Specifications**

CHARACTERISTIC	SPECIFICATION/DESCRIPTION		
RF transmission rate	1.536 Mbps		
Ethernet throughput	935 Kbps		
Output power	+21 dBm (125 mW), (4 Watts EIRP with 15 dBi antenna)		
Receiver sensitivity	-97 dBm at 10 <sup>-4</sup> Bit Error Rate		
Range	Up to 1000 ft (300 m) indoor w/2.1 dBi dipole antennas		
	Up to 2 mi (3.2 km) outdoor line of sight w/2.1 dBi dipole antennas		
	Up to 15 mi (24 km) outdoor line of sight w/high-gain antennas		
Radio channels/band-	12 channels (6 in International version) with 2.0833 MHz spacing		
width	and 1.75 MHz occupied bandwidth		
Manual frequency select	Channel selected with DIP switch or via web browser interface		
Connector types	RF RPTNC female / Ethernet RJ-45 / Power Jack P5-2.1 mm		
	center positive		
Status LEDs	Power, Ethernet Link, RF RX, RF TX, 4/Channel, and 6/Link Qual-		
	ity		
Error correction tech-	Sub-block error detection and retransmission		
nique			
Adjacent band rejection	SAW receiver filter attenuates cellular and pager interference		
Regulator type	Switching regulator		
Browser management	QoS Statistics, Network Settings, Spectrum Analyzer and Firmware		
tools	Upgrading		
Power consumption	Transmit: 1.7 Watts Receive: 0.8 Watts		
Voltage	Power over Ethernet 9-48 VDC pins 4/5 positive and 7/8 ground		
Temperature range	Radio/Enclosure: -40 C to 70 C; POE Injector: -40 C to 85 C;		
	Pwr Supply: 0 to 40 C		
Transmit current draw	175 mA at 9 VDC		
	140 mA at 12 VDC		
	35 mA at 48 VDC		
Size	9.22"L x 3.60"W x 2.19"H, 320 grams		
Weatherproofing	The XPress enclosure is built and tested for weatherproof instal-		
	lation. The PoE injector and power supply are not weatherproof,		
	and should be installed indoors.		
Certifications/Compli-	FCC part 15		
ance	Industry Canada		
	Contains FCC ID: R4N-AW900MR and IC: 5305A-AW900MR		
	UL 00700-1 CSA C22 2 No. 40050 1 E112700		
	CSA C22.2, NO. 00930-1, ETT2/90		
	CLID		

Technical support (801) 765-9885

## Contents

#### XEB09-CISA(-W):

- One XEB RF Modem ("-W" = International variant)
- One 2.1 dBi Weatherproof Dipole Antenna
- One 12 VDC Power Supply
- One Power over Ethernet Injector

#### XEB09-CIPA(-W):

• Two each of the items above (Ethernet cables are not included.)

## **Operational Summary**

The XPress Ethernet Bridge allows the user to create a long-range, wireless Ethernet network with up to 16 active (63 total) subscriber units per access point.

Configuring a wireless link with the XPress requires the establishment of six elements:

- Each radio must know whether it is to be an access point (AP) or subscriber unit (SU).
- Each radio must have an IP address that is unique among all others on the same network.
- The AP must know how many SUs are expecting communication with it.
- The AP and any given SU must agree on which radio frequency channel they are using. This can be manually set or allowed to change automatically.
- The SU must be assigned a unique subscriber ID to specify which time division slot it will use when communicating with the AP.
- The AP and any given SU must share a common 128-bit encryption key.

The access point (AP) automatically scans for the best of the 12 available radio frequency channels, encrypts Ethernet data received from the network, and transmits it wirelessly to the correct subscriber unit (SU). The AP is constantly monitoring the radio link and can automatically change the channel if performance is degraded due to interference. If two AP units are very close to one another, they may interfere if operating on adjacent frequency channels. Place them at least 10 feet apart or manually select non-adjacent channels for their operation. Also, the SU should be placed at least 10 feet from the AP to avoid overloading the radio's receiver.

Any 10/100 BaseT Ethernet client device (ECD) can be connected to an XPress subscriber unit. Each SU encrypts Ethernet traffic received from the attached ECD and transmits the data wirelessly to its AP. Each SU can be plugged directly into an ECD without adding drivers or loading software. Essentially, once the AP/SU pair is configured and running it behaves like a continuous Ethernet cable.

## **Physical Dimensions**



#### **900 MHz Channels**

Channel	US/Canada	International	Center Frequency		
0	х	х	Auto Mode		
1	x		903.12500 MHz		
2	x		905.20833 MHz		
3	x		907.29167 MHz		
4	х		909.37500 MHz		
5	х		911.45833 MHz		
6	x		913.54167 MHz		
7	х	х	915.62500 MHz		
8	х	х	917.70833 MHz		
9	х	х	919.79167 MHz		
10	x	х	921.87500 MHz		
11	х	х	923.95833 MHz		
12	x	х	926.04167 MHz		

Technical support (801) 765-9885

#### Setup

1. Consult IT - each XPress radio comes default with a static IP address of 192.168.17.17. We recommend connecting each radio to a stand-alone computer disconnected from any shared network, and consulting with your IT dept before connecting them to any shared network.

2. Connect hardware - attach antenna to the XPress radio; attach Ethernet cable (straight or cross-over) between the XPress radio and the "DATA + PWR" jack on the POE injector; attach power supply to the POE injector; attach another Ethernet cable (straight or cross-over) between your Ethernet device and the "DATA" jack on the POE injector.

3. Configure radios\* - use either the Digital Setup method (see below), or use the old DIP switch method (see page 3 of the 90000888\_B.pdf manual at http://www.digi.com/products/ wireless/xpress.jsp#docs).

\* Note: XEB09-CIPA(-W) radios come pre-configured as a paired set. No configuration is required.

## **Digital Setup**

1. Digital configuration is done by means of the XPress built-in browser interface. It should be powered on and connected at least temporarily to a network containing a computer that can run a conventional web browser.

2. Download the Digi IP Discovery Utility from our website and extract changer\_DIGI.exe from the zip archive, placing it on your desktop or in a convenient folder.

```
http://www.digi.com/products/wireless/xpress.jsp#docs
```

Note that this utility only runs on MS Windows, not linux or MAC. If you must use a non-Windows computer for configuration, make sure your subnet mask allows your computer to see 192.168.17.17. Connect to that default IP address with your web browser, continuing the setup procedure with step 6.

3. Run the IP Discovery Utility, changer\_DIGI.exe and you should see a window similar to this:



The XPress should appear in the list at the default IP address of 192.168.17.17. If it does not, click "Search" to regenerate the list. If it still does not appear, you have a connection issue and need to re-examine the cabling or you may have a firewall issue on your computer.

4. Double click the list item that refers to the XPress being configured. You should see a second window that is similar to the picture on the next page:

#### XPress Ethernet Bridge User's Manual



The information on the left is the current status of the radio, while the boxes on the right allow you to change it. It is important that the IP address of the XPress is in the same subnet as your computer. For example, if the subnet mask is 255.255.255.0 (a class C network), the first three number groups of the IP address must match. Choose your desired parameters and click "Apply."

5. Make note of the chosen IP address and password, then click "Go to Device Web Page." This will cause your default web browser to launch with the device IP address in the browser address bar. Or you may launch the browser on your own and enter the web page address manually: http://[the IP address you just set].

6. The browser page that loads first shows the current device information and QoS statistics and provides a login at the upper right. Log in using the password you just specified (or "password" if you kept the default). If the login succeeds, you will see an admin page similar to this:

xTR - Admin - Mozilla Firefox				a group	
ile Edit View History Bookmarks	Iools <u>H</u> elp				
xTR - Admin	+				
		///////////////////////////////////////			
	Version: 1.	54.4067		Logout	
Diak	MAC Address: 00	21:74:00:08:19	Defeat New	Europ 10 and	
Contraction of the second seco	Ethernet: 10	0 Mbps Full Duplex	Mellesillada	Every to sec •	
	Uptime: 18	days 01h 59:19			
	Need help? O	nline FAQ available	at www.DIGI.com		
Statistics		Devi	ce Information		
Radio RSSI	-38 dBm		Device Type:	Access Point	
Radio Block Error Rate	0.0 %		# of Subscriber IDs Issued:	3	
Radio Total Packets	5173552		Current RF Channel:	12	
Radio Failed Packets	911		Connected Subscribers:	2	
Radio Passed Packets	5172641		RF Connected:	Yes	
Radio Broadcast Packets	1675960		Radio Active:	Active	
Radio Unicast Packets	3497592		Product Code:	4	
Radio Average TX Size	217 bytes		Radio Version:	3	
Radio Alferage for Size	100 09165		Raulo I innivare Release.	015	
Device Settings					
		_			
	Description		Value		
Device	Password	password			
		O Line DID 2.9	coloction: 0 (outo observal col	ant mode)	
RF	Channel	Use Dim 3-6 selection: 0 (auto channel select mode)		ect mode)	
		I2 (overrides the current DIP 3-8 selection)			
	IP Address	192.168.1.229	(#.#.#.#)		
	Network Mask	255.255.255.0	(#.#.#.#)		
Network	Default Gateway	192.168.1.1	(#.#.#.#)		
	HTTP Port	8011 (decin	nal 1-65535)		
				Apply	Cancel
• Luu Done					

7. The admin page has sections similar to the login page showing radio statistics and device information plus it adds several new sections. The Device Settings section allows setting the network information and choosing an RF frequency channel. The default is to allow the radio to choose its own frequency based on minimizing interference. If you set a fixed channel, make sure the AP and all SUs use the same one. References to DIPs on this and the next web page refer to switches inside the radio that are used in the legacy method of configuration and may be ignored when using the browser method.

Technical support (801) 765-9885

#### User's Manual XPress Ethernet Bridge

If you scroll down in the Admin browser page, you will come to three more sections:

- A graphical spectrum analyzer display that may help you to select radio channels that avoid interference
- A section to be used if an update to the XPress firmware is required. Note that there are two possible firmware loads for this unit, one for compatibility with older XPress Ethernet Bridge Multipoint radios (XEB09-Bxxx), and an international version that limits the frequency band to 915-928 MHz (Channels 7 through 12). Latest firmware is found online at ftp://ftp1.digi.com/support/firmware/update/xpress/. To change firmware, download the desired .bin and .webbin files, and click Upload Firmware to install the files one at a time. Please note that we recommend contacting Technical support before changing firmware.
- An Advanced Links section with a dire warning about advanced users only.

Despite the warning, you will need to click the "Advanced Admin" button in order to set the device type, ID and encryption key. You should then see a page similar to this:

xTR - Advanced Admin - Mozilla Firefox		
Eile Edit View Higtory Bookmarks Io	ols Help	
XIK - Advanced Admin	*	
Digit	Version: 1.54.406 MAC Address: 00:21:74 Ethernet: 100 Mbp Uptime: 18 days	7 Logout Back to Admin Page 100 08:19 os Full Duplex Co h0 05 5
	Need help? Online F	FAQ available at www.DIGI.com
	Warning! These setting an Please pro	e only for use by advanced users! cceed with caution.
Device Settings		
	Description	Value
Davice	Туре:	Access Point (override DIP 1 selection) Subscriber Unit (DIP 1 selection)
Device.	# of Subscriber IDs Issued:	An AP can issue from 1 to 63 SU IDs. 3 (decimal 1-63)
		Z Enable User Specified Keys
Encryption:	Network Name (32-bit):	30000-30000 0000-0155 (hex)
	Encryption Key (128-bit):	x000-x000-x000-x000-x000-x000-x000-x00
		Apply Cancel
Reset the Device		ResetDevice

- 8. On the Advanced Admin page, set the parameters as follows:
  - Choose Device Type: Access Point or Subscriber Unit.
  - For Subscriber Units, assign unique ID numbers in numeric order from 1 to 63.
  - For an Access Point, enter the number of Subscriber Units that will be communicating with it.
  - Click the box labeled "Enable User Specified Keys."
  - Choose an 8-digit hex (0-9 and A-F) Network Name that will be common among the AP and its SUs and enter it. The hyphen is required.
  - Choose a 32-digit hex encryption key and enter it. Again, the hyphens are required. This key must match between the AP and the SU so make a note of it as well.

After entering the parameters, click the "Apply" button to save them to the radio.

Technical support (801) 765-9885 PAGE 7 www.digi
--

9. When all of the radios are keyed and operating, connect them to your network and Ethernet devices as desired and cycle the radio's power to begin normal operation. Now, browser mamagement of the SUs can be performed over the wireless network. Note: avoid plugging actively linked radios into the same switch because this will corrupt its routing table and may cause network problems just as if you had plugged a CAT5 cable directly between two ports of a switch.

#### **FCC Certification**

The XPress Ethernet Bridge complies with Part 15 of the FCC rules and regulations. Compliance with labeling requirements, FCC notices and antenna regulations is required.

**IMPORTANT:** The XPress Ethernet Bridge has been certified by the FCC for use with other products without any further certification (as per FCC section 2.1091). Changes or modifications not expressly approved by Digi International could void the user's authority to operate the equipment.

**IMPORTANT:** The XPress Ethernet Bridge has been certified for fixed base station and mobile applications. If modules will be used for portable applications, the device must undergo SAR testing.

**ANTENNAS:** The XPress Ethernet Bridge is approved for use with the following weatherproof antennas: A09-HTM-675 (2.1 dBi dipole RPTNC male), A09-Y10TM-P10I (10 dBi Yagi RPTNC male), A09-Y15TM-P10I (15 dBi Yagi RPTNC male), A09-Y8NF (8.1 dBi Yagi N female), A09-Y11NF (11.1 dBi Yagi N female), A09-Y15NF (15.1 dBi Yagi N female).

#### **Limited Warranty**

This product is warranted to the original purchaser for normal use for a period of one year from the date of purchase. If a defect covered under this warranty occurs, Digi International will repair or replace the defective part, at its option, at no cost. This warranty does not cover defects resulting from misuse or modification of the product.

© 2010 by Digi International, Inc. All rights reserved

Digi International, Inc. 11001 Bren Road East Minnetonka, MN 55343

Sales: (877) 912-3444 Technical Support: (801) 765-9885 Business Hours: 8am - 5pm, U.S. Mountain Time



PN:(1P)90001146-88 A

Technical support (801) 765-9885

PAGE 8

www.digi.com