

ADS1202 Modular EVM

User's Guide

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Following are URLs where you can obtain information on other Texas Instruments products & application solutions:

Products		Applications	
Amplifiers	amplifier.ti.com	Audio	www.ti.com/audio
Data Converters	dataconverter.ti.com	Automotive	www.ti.com/automotive
DSP	dsp.ti.com	Broadband	www.ti.com/broadband
Interface	interface.ti.com	Digital Control	www.ti.com/digitalcontrol
Logic	logic.ti.com	Military	www.ti.com/military
Power Mgmt	power.ti.com	Optical Networking	www.ti.com/opticalnetwork
Microcontrollers	microcontroller.ti.com	Security	www.ti.com/security
		Telephony	www.ti.com/telephony
		Video & Imaging	www.ti.com/video
		Wireless	www.ti.com/wireless

Mailing Address: Texas Instruments
Post Office Box 655303 Dallas, Texas 75265

EVM IMPORTANT NOTICE

Texas Instruments (TI) provides the enclosed product(s) under the following conditions:

This evaluation kit being sold by TI is intended for use for **ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY** and is not considered by TI to be fit for commercial use. As such, the goods being provided may not be complete in terms of required design-, marketing-, and/or manufacturing-related protective considerations, including product safety measures typically found in the end product incorporating the goods. As a prototype, this product does not fall within the scope of the European Union directive on electromagnetic compatibility and therefore may not meet the technical requirements of the directive.

Should this evaluation kit not meet the specifications indicated in the EVM User's Guide, the kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods. Please be aware that the products received may not be regulatory compliant or agency certified (FCC, UL, CE, etc.). Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge.

EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

TI currently deals with a variety of customers for products, and therefore our arrangement with the user **is not exclusive**.

TI assumes **no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein**.

Please read the EVM User's Guide and, specifically, the EVM Warnings and Restrictions notice in the EVM User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For further safety concerns, please contact the TI application engineer.

Persons handling the product must have electronics training and observe good laboratory practice standards.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used.

Mailing Address:

Texas Instruments
Post Office Box 655303
Dallas, Texas 75265

EVM WARNINGS AND RESTRICTIONS

It is important to operate this EVM within the input voltage range of ± 125 mV and the output voltage range of 0 V to 5 V.

Exceeding the specified input range may cause unexpected operation and/or irreversible damage to the EVM. If there are questions concerning the input range, please contact a TI field representative prior to connecting the input power.

Applying loads outside of the specified output range may result in unintended operation and/or possible permanent damage to the EVM. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative.

During normal operation, some circuit components may have case temperatures greater than 23°C. The EVM is designed to operate properly with certain components above 50°C as long as the input and output ranges are maintained. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors. These types of devices can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during operation, please be aware that these devices may be very warm to the touch.

Mailing Address:

Texas Instruments
Post Office Box 655303
Dallas, Texas 75265

Read This First

About This Manual

This users guide describes the characteristics, operation, and use of the ADS1202 Modular EVM. A complete circuit description as well as schematic diagram is included.

How to Use This Manual

This document contains the following chapters:

- ☐ Chapter 1—EVM Overview
- ☐ Chapter 2—Power Supply Options
- ☐ Chapter 3—EVM Operation
- ☐ Chapter 4—ADS1202 Modular EVM BOM and Schematic

Information About Cautions and Warnings

This book may contain cautions and warnings.

This is an example of a caution statement.

A caution statement describes a situation that could potentially damage your software or equipment.

This is an example of a warning statement.

A warning statement describes a situation that could potentially cause harm to you.

The information in a caution or a warning is provided for your protection. Please read each caution and warning carefully.

Related Documentation From Texas Instruments

To obtain a copy of any of the following TI documents, call the Texas Instruments Literature Response Center at (800) 477-8924 or the Product Information Center (PIC) at (972) 644-5580. When ordering, please identify this booklet by its title and literature number. Updated documents can also be obtained through our website at www.ti.com.

Data Sheet:

ADS1202

Literature Number:

SBAS275

User's Guide:

5-6K Interface Board EVM

Literature Number:

SLAU104

FCC Warning

This equipment is intended for use in a laboratory test environment only. It generates, uses, and can radiate radio frequency energy and has not been tested for compliance with the limits of computing devices pursuant to subpart J of part 15 of FCC rules, which are designed to provide reasonable protection against radio frequency interference. Operation of this equipment in other environments may cause interference with radio communications, in which case the user at his own expense will be required to take whatever measures may be required to correct this interference.

Trademarks

TI logo is a trademark of Texas Instruments.

Contents

1	EVM Overview	1-1
1.1	Analog Interface	1-2
1.2	Digital Interface	1-2
2	Power Supply Options	2-1
3	EVM Operation	3-1
4	ADS1202 Modular EVM BOM and Schematic	4-1
4.1	ADS1202 Modular EVM BOM	4-2
4.2	Schematic	4-3

Tables

4-1.	Bill of Materials	4-2
------	-------------------	-----

EVM Overview

The ADS1202 modular EVM provides direct modulator output to a host processor and allows all operating modes of the ADS1202. It provides various isolation options for a variety of applications.

The new modular EVM form factor allows for direct evaluation of the ADC's performance and operating characteristics. This EVM is compatible with the 5-6K Interface Board (SLAU104) from Texas Instruments.

- ☐ Direct modulator output
- ☐ Various isolation options
- ☐ Direct operation with a variety of DSK platforms from Texas Instruments

Topic	Page
1.1 Analog Interface	1-2
1.2 Digital Interface	1-2

1.1 Analog Interface

The ADS1202 modular EVM is designed for easy interfacing to multiple analog sources. Samtec part numbers SSW-110-22-F-D-VS-K and TSM-110-01-T-DV-P provide a convenient 10-pin dual row header/socket combination at J1. Connector J1 provides access to the ADS1202 input pins. The modulator + input terminal is connected to pin 2, the - input terminal is connected to pin 4. Pins 1 - 19 are connected to analog ground.

1.2 Digital Interface

The ADS1202 modular EVM is designed for easy interfacing to multiple control platforms. Samtec part numbers SSW-110-22-F-D-VS-K and TSM-110-01-T-DV-P provide a convenient 10-pin dual row header/socket combination at J2. This header/socket combination provides access to the clock and data output pins of the ADS1202 Sigma Delta modulator.

Signal		Description
J2.1	Unused	
J2.3	SCLK	Serial clock input (for use with MODE 3 Operation)
J2.5	CLKR	Modulator clock output (for use with MODES 0, 1 and 2)
J2.7	Unused	
J2.9	Unused	
J2.11	Unused	
J2.13	SDO	Bit stream data output from ADS1202
J2.15	Unused	
J2.17	Unused	
J2.19	SPARE	

Power Supply Options

The ADS1202 modular EVM board requires 5-V dc for the ADS1202 circuit. When used in combination with the 5-6K interface boards, J5 (located on the bottom side of the PWB) provides connection to the common power bus described in document SLAU104. For isolated applications, J4 provides power to isolation components including optocouplers or LVDS drivers. For evaluation purposes, TP3 and TP4 can be shorted together to provide a common power source across the isolation boundary. Similarly, TP2 and TP6 can be shorted together to provide a common ground.

When used as a stand alone EVM, the ADS1202 power can be applied to J3. While filters are provided for all power supply inputs, optimal performance of the EVM requires a clean, well-regulated power source.

EVM Operation

The analog input source can be applied directly to J1 pins 2 and 4. Series resistors R10 and R11 as well as capacitors C8, C9, and C10 provide filtering to the input of the ADS1202.

The digital control signals can be applied directly to J2 (top or bottom side). The ADS1202 modular EVM can also be connected directly to a DSP interface board.

Footprints are provided on the PWB which allow a variety of isolation options. Transformers, optoisolators or optocouplers may be installed for evaluation of different isolation techniques.


The EVM uses two *solder shorts* at position U3 to provide direct nonisolated operation of the ADS1202, for isolated operation, these shorts may be replaced with isolation devices such as the IL711 from NVE (close W3 pins 2-3), HCPL-2631 optocouplers (close W3 pins 1-2) or transformer circuits such as those described in application note SLAA096.

The operating mode of the ADS1202 can be controlled by placing shunt jumpers on W1 and W2. When the jumper is open (not installed) logic 1 is applied to the mode pins. W1 controls M0, W2 controls M1. The EVM is configured with both W1 and W2 closed, providing Mode 0 operation.


Jumper		Description
W1	W2	
closed	closed	Mode 0 operation – processor reads MDAT on rising clock edge only
open	closed	Mode 1 operation – processor reads MDAT on <i>every</i> clock edge
closed	open	Mode 2 operation – Manchester decoding required
open	open	Mode 3 operation – requires external clock (optional - short TP1 to TP7)

To verify the ADS1202EVM is functional, arrange W1 and W2 for Mode 0 operation by ensuring the shunt jumpers are installed (factory default conditions). Apply 5-V power to the EVM through J3. Apply a 200-kHz sinusoidal wave (250 mV_{PP}) to J1.2 referenced to J1.4.

Using an oscilloscope view the MCLK and MDAT output signals on J2.5 and J2.13 respectively. The outputs should look similar to those in the following figure:



Slowly increase the time base of the oscilloscope. As the time base increases, the sine wave applied to the input terminals should begin to appear on the oscilloscope screen as shown below. These screen shots were taken using a Tektronics digital oscilloscope model TDS-754D set for *Hi Resolution* mode.



ADS1202 Modular EVM BOM and Schematic

This chapter contains the bill of materials and the schematic

Topic	Page
4.1 Bill of Materials	4-2
4.2 Schematic	4-3

4.1 ADS1202 Modular EVM BOM

The following table contains a complete bill of materials for the ADS1202 EVM.

Table 4- 1. Bill of Materials

Designators	Description	Manufacturer	Mfg. Part Number
C1, C8	1 nF, 0805, ceramic, NPO, 50 V, 5%	PhyComp	0805CG102J9B200
C2, C3, C4, C9, C10	0.1 μ F, 0805, ceramic, X7R, 50 V, 10%	Panasonic	ECJ-2YB1H104K
C5, C6	33 μ F, 16V, Aluminum, Size C	Cornell Dubilier	AVS336M16C12T
C7, C8, C11-C15	Not installed		
FB1, FB2	SMT, EMI beads, Z=47 Ω at 100 MHz	Fair-Rite	2743019447
J1, J2 (top side)	10 Pin, dual row SMT header (20 positive)	Samtec	TSM-110-01-T-DV-P
J1B, J2B (bottom side)	10 Pin, dual row, SMT socket (20 positive)	Samtec	SSW-110-22-F-D-VS-K
J3, J4	2 Terminal screw connector	OST	ED1514
J5 (bottom side)	4 Pin, dual row, TH header (8 positive.)	Samtec	SSW-105-22-F-D-VS-K
R1, R2	10 k Ω , 0805, 0.1 W resistor	Yageo America	9C08052A1002JLHFT
R3, R5, R10, R11	33 Ω , 0805, 5%, 0.1 W resistor	Yageo America	9C08052A33R0JLHFT
R4, R6-R9, R12-R16	Not installed		
TP1, TP3, TP4, TP5, TP7	Red test point loop	Keystone	5000
TP2, TP6	Black test point loop	Keystone	5001
U1	ADS1202	Texas Instruments	ADS1202
U2, U3	Not installed		
T1, T2	Not installed		
W1, W2	2 Pin header	Samtec	TSW-102-07-L-S
W3	3 Pin header (not installed)	Samtec	TSW-103-07-L-S

4.2 Schematic

The schematic diagrams are shown on the following pages.

Revision History		
REV	ECN Number	Approved



12500 TI Blvd. Dallas, Texas 75243

Title: ADS1202 - miniEVM Schematic

Drawn By: Tom Hendrick
Engineer: Tom Hendrick
FILE:

SIZE: B DATE: 8-Aug-2003 REV: A
SHEET: 1 OF: 1

