



ASSEMBLY INSTRUCTIONS:

- Mount cable extension (item 1) to rear tapped combination rail centered to drawer or shelf. Use 10-32 screws (item 2) thru oblong slots on flat hinge bracket as shown in assembly view.
- Check extension in closed position by pushing drawer/shelf fully closed. Min distance of .67" (17mm) allowed. See Fig. 1. If extension is binding adjust rear combination rail towards rear until .67" (17mm) or greater is achieved.
- Mark hole centers on drawer/shelf thru oblong slots, center punch and drill 13/64 (.203)/5.2mm dia. hole as shown in assembly view. Mount extension to drawer or shelf using 10-32 screw, flat washer and hex nut (items 2, 3 & 4).
- With cable extension mounted to the corner vertical and drawer/shelf, pull drawer/shelf out and check that the extension does not exceed the 29.2" / 742mm MAX EXTENSION shown in fig. 2.
- Fasten ribbon cable to extension using cable ties provided thru desired slots on extension.

PARTS LIST

ITEM No.	DESCRIPTION	QTY
1	CABLE EXTENSION	1
2	10-32 SCREW	4
3	#10 FLAT WASHER	2
4	10-32 HEX NUT	2

TOOL BOX

