

# Datamate Tooling

POSITIONER	HAND CRIMP TOOL										
<div> <ul style="list-style-type: none"> <li>Used with hand crimp tool shown opposite.</li> </ul> </div> <div>  </div> <div> <table> <tr> <th colspan="2">ORDER CODE</th></tr> <tr> <td>Male &amp; female Crimp</td><td><b>T5747</b></td></tr> <tr> <td>Power Crimp</td><td><b>Z80-058</b></td></tr> <tr> <td>Male Jackscrew Crimp</td><td><b>Z80-193</b></td></tr> </table> </div>	ORDER CODE		Male & female Crimp	<b>T5747</b>	Power Crimp	<b>Z80-058</b>	Male Jackscrew Crimp	<b>Z80-193</b>	<div> <ul style="list-style-type: none"> <li>Standard circular crimp tool BS5210-3A-300 and MIL specification M22520/2-01.</li> <li>Precision tool with ratchet mechanism and 8-indent form.</li> <li>Must be used with positioner opposite.</li> <li>Instruction sheet available.</li> </ul> </div> <div>  </div> <div> <table> <tr> <th>ORDER CODE</th><td><b>M22520/2-01</b></td></tr> </table> </div>	ORDER CODE	<b>M22520/2-01</b>
ORDER CODE											
Male & female Crimp	<b>T5747</b>										
Power Crimp	<b>Z80-058</b>										
Male Jackscrew Crimp	<b>Z80-193</b>										
ORDER CODE	<b>M22520/2-01</b>										
SEPARATOR TOOL	INSERTION/REMOVAL TOOL										
<div> <ul style="list-style-type: none"> <li>Recommended for unplugging latched connectors (tool releases the latches prior to disengagement).</li> <li>Can also be used with unlatched and friction lock connectors.</li> <li>Suitable for all sizes.</li> </ul> </div> <div>  </div> <div> <table> <tr> <th>ORDER CODE</th><td><b>T5746</b></td></tr> </table> </div>	ORDER CODE	<b>T5746</b>	<div> <ul style="list-style-type: none"> <li>For inserting crimped socket contacts into the rear of mouldings.</li> <li>Instruction sheet available.</li> <li>Suitable for all Datamate signal contacts.</li> </ul> </div> <div>  </div> <div> <table> <tr> <th>ORDER CODE</th><td><b>Z80-280</b></td></tr> </table> </div>	ORDER CODE	<b>Z80-280</b>						
ORDER CODE	<b>T5746</b>										
ORDER CODE	<b>Z80-280</b>										

www.harwin.com