# TPA4860 Audio Power Amplifier Evaluation Module

DATA MANUAL: SLOU003

Date: July 1997



#### **IMPORTANT NOTICE**

Texas Instruments and its subsidiaries (TI) reserve the right to make changes to their products or to discontinue any product or service without notice, and advise customers to obtain the latest version of relevant information to verify, before placing orders, that information being relied on is current and complete. All products are sold subject to the terms and conditions of sale supplied at the time of order acknowledgement, including those pertaining to warranty, patent infringement, and limitation of liability.

TI warrants performance of its semiconductor products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are utilized to the extent TI deems necessary to support this warranty. Specific testing of all parameters of each device is not necessarily performed, except those mandated by government requirements.

CERTAIN APPLICATIONS USING SEMICONDUCTOR PRODUCTS MAY INVOLVE POTENTIAL RISKS OF DEATH, PERSONAL INJURY, OR SEVERE PROPERTY OR ENVIRONMENTAL DAMAGE ("CRITICAL APPLICATIONS"). TI SEMICONDUCTOR PRODUCTS ARE NOT DESIGNED, AUTHORIZED, OR WARRANTED TO BE SUITABLE FOR USE IN LIFE-SUPPORT DEVICES OR SYSTEMS OR OTHER CRITICAL APPLICATIONS. INCLUSION OF TI PRODUCTS IN SUCH APPLICATIONS IS UNDERSTOOD TO BE FULLY AT THE CUSTOMER'S RISK.

In order to minimize risks associated with the customer's applications, adequate design and operating safeguards must be provided by the customer to minimize inherent or procedural hazards.

TI assumes no liability for applications assistance or customer product design. TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right of TI covering or relating to any combination, machine, or process in which such semiconductor products or services might be or are used. TI's publication of information regarding any third party's products or services does not constitute TI's approval, warranty or endorsement thereof.

Copyright © 1999, Texas Instruments Incorporated

#### **TRADEMARKS**

TI is a trademark of Texas Instruments Incorporated.

Other brands and names are the property of their respective owners.

## **Contents**

Abstract	7
I. Quick Start	8
1. Layout Definition	9
2. Operation	11
3. Input/Output Connections	12
4. Specifications	14
5. Layout	17
6. Bill of Materials	18
Figure	
Figures	
figure 1. TPA4860 Audio Amplifier EVM Circuit Component Placement	
igure 2. TPA4860 EVM Schematic	
Figure 3. TPA4860 Circuit Application Hookup Diagram, BTL Drive	13
igure 4. TPA4860 Circuit Application Hookup Diagram, SE Drive	14

### If You need Assistance...

If You Want to	Do This	
Request more information about Call the Texas instruments Mixed Signal Products	ne PIC† hotline: (972) 644-5580	
	or send a fax to the PIC: (972) 480-7800	
	or write to: Texas Instruments Incorporated Product Information Center, MS 3123 P.O. Box 660246 Dallas, Texas 75266	
Order Texas Instruments documentation	Call the PIC† hotline: (972) 644-5580	
Ask questions about product operation or report suspected problems	Call the PIC† hotline: <b>(972) 644-5580</b>	
Report mistakes in this document or any other TI Mixed Signal Products documentation	Send a fax to MSP Marketing Documentation Correction: (214) 480-3160	
	or send your comments to: Texas Instruments Incorporated MSP Marketing Documentation Correction, MS 8710 P.O. Box 660199 Dallas, Texas 75266-0199	

<sup>†</sup> Texas Instruments Product Information Center

## Operating the TPA4860 Audio Power Amplifier Sample EVM (SLOP098)

#### **Abstract**

The Texas Instruments (TI™) TPA4860 audio power amplifier sample evaluation module (EVM) (SLOP098) incorporates the circuitry required for designers of notebook, cellular, and other hand-held audio systems to evaluate the performance of the TPA4860 audio power amplifier without investing in a PC board layout and assembly (see the application note in the TPA4860 data sheet (SLOS164) for a description of the circuit configuration and selection of components).

The TPA4860 EVM plugs into TI's Plug-N-Play Audio Amplifier Evaluation Platform (SLOP097). The platform is a convenient evaluation vehicle incorporating the required circuitry to power and test all of its compatible audio power amplifier EVMs and thus eliminate the need for external implementation.

The TPA4860 EVM can be used with the TPA4861 EVM (SLOP099) to derive various drive configurations.



#### I. Quick Start

Included below is a quick checklist of setup steps to get the TPA4860 up and running fast.

- 1. Set S1 to the "off" position.
- 2. Align the TPA4860 with either socket U3 or U4, such that the side with 4 pins is adjacent to the speaker connections, and firmly connect it to the P-n-P board.
- 3. Check the power supply jumper setting on the P-n-P board. To use battery power select JP3, to select wall mount AC/DC power select JP2, or to use a bench type DC power supply select JP1 Note: be sure only one of these three jumpers is connected by a shorting block.
- 4. Check the mode/mute jumper circuitry (JP6, JP7, JP8). To begin with, set JP7 to Lo and JP8 to Hi, and JP6 to mute. This arrangement causes the TPA4860 to be active when no headphones are present. In the future refer to Table 1 in the P-n-P board Application Report (SLOU001) to adjust these settings.
- 5. Check the Audio Input Path Selection Circuitry, if there is no EVM present in U1, then set S2 to the "off" position
- 6. Set S3 to the "U5" position (only if a headphone EVM is connected to U5).
- 7. Connect a mono audio source to either J3 (U3) or J5 (U4) (or both), or connect a stereo audio source to J4.
- 8. Connect an 8 ohm speaker(s) to either (or both of) the RCA jacks at J7 (U3) and J9 (U4) or to the wire clips at J8.
- 9. Connect your power supply to the P-n-P board.
- 10. Push S1 to the "on" position. Activate your audio source

Step 10 will activate the EVMs present on the P-n-P. If you do not hear sound, please consult the troubleshooting section of the P-n-P Board application report (SLOU001).


To use power from J1, J2, or B1 a DC/DC converter must be present at U6. If no converter is present, apply DC power to J6.



## 1. Layout Definition

The TPA4860 is a CMOS device designed primarily for bridge tied load (BTL) operation (please consult the TPA4860 data sheet, SLOS164) in notebook, cellular, and other hand-held audio systems. The typical supply current of 3.5 mA at 5 V makes the TPA4860 an ideal upgrade for battery powered applications. The TPA4860 also includes headphone interface logic circuitry to facilitate headphone applications. Figure 1 shows The TPA4860 audio amplifier EVM layout.

Figure 1. TPA4860 Audio Amplifier EVM Circuit Component Placement



Legend:



U1 - TPA4860D Mono 1 W Audio Amplifier

C1, C3 - Capacitor, 2.2 <sub>μ</sub>F Ceramic

C2 - Capacitor, 1.0 μF Ceramic

C4 - Capacitor, 0.1 μF Ceramic

C5 - Capacitor, 10 µF Electrolytic

C6 - Capacitor, 5 pF Ceramic

R1, R2, R3 - Resistor, 20 k  $\Omega$  Carbon

R4 - Potentiometer, 200 k  $\Omega$  3/4 Turn

R5 - Resistor, 51  $\Omega$  Carbon

S1, - Switch, Normally Open, Momentary



The TPA4860 sample EVM offers the following key features:

- Mono Bridge Tied Load (BTL) drive for 8 ohm speakers and above
- □ SNS output and shutdown input
- □ The SNS output follows the logical OR combination of HP1 and HP2. Such that IN1, IN2 headphone sense inputs used as mute switch inputs
- □ Shutdown Input
- □ Gain Control Pot R4

Lower gains produce better distortion performance (see the TPA4860 data sheet for more information). Gain vs total harmonic distortion (THD) should be considered in each application. The gain adjustment range on the EVM is 2 to 22.

#### NOTE:

Most speakers have significantly worse distortion than the TPA4860 at high gain settings.

The TPA4860 is packaged in a 16-pin small-outline integrated circuit (SOIC), which is adequate for most room-temperature applications.

The thermal layout of the EVM is important because linear audio power amplifiers dissipate large amounts of heat during operation (see the TPA4860 data sheet (SLOS164) for details on heat dissipation for 5 V and 3.3 V applications). All GND pins must be connected to as much copper area as possible on the surface of the PC board. These copper areas should then be connected with vias to ground plane layers inside the PC board. These connections become even more important in high ambient temperature applications.

The connection pins of the TPA4860 EVM are on a 0.1" grid for easy interface to standard plugboard-based prototype systems.



## 2. Operation

The TPA4860 EVM is compatible with the TI Plug-N-Play Audio Amplifier Evaluation Platform slots U3 and U4.

No soldering is required for use in the plug-and-play (PnP) system. The evaluation platform includes standard speaker jacks, RCA jacks, and 1/8" stereo input jacks for quick and easy evaluation of all TI TPA series audio power amplifiers.

The TPA302 EVM (SLOP100) is recommended for use as the headphone drive.

For standalone use, connections diagrams are shown in figures 3 and 4.



## 3. Input/Output Connections

Figure 2. TPA4860 EVM Schematic





Figure 3 shows the TPA4860 connections diagram for stereo BTL drive configuration. The BTL configuration eliminates the large output coupling capacitors and quadruples the available output power when compared to single-ended (SE) solutions. As a result, the total PC board space required is much smaller than SE configurations of the same output power. A standard 1/8" stereo input jack provides a convenient connection to CD players and other commercial sources of audio signals.



Figure 3. TPA4860 Circuit Application Connections Diagram, BTL Drive

## TPA4860 Sample EVM Circuit

03/10/97



EVM1 drives the right channel and EVM2 drives the left channel. Power levels of 1 W rms are possible with 8 ohm speakers and a steady-state sine wave input. Real music power and peak-to-valley ratios vary according to the type of music played. A 9 to 12 dB peak to average ratio is a good figure for rough calculations. In terms of power, this means 1 W peaks come from an average power of 63 mW for 12 dB and 126 mW for 9 dB as described in the following equation:

 $Headroom_{dB} = 10 Log (P_{max}/P_{avg})$ 


Figure 4 shows the TPA4860 connections diagram for stereo SE drive configuration. The SE drive configuration requires the output from Out— to be connected to the Dummy Load (DL) input to prevent the unused output from becoming unstable and possibly oscillating during operation. Oscillations cause unwanted noise that can couple into other circuits (see the TPA4860 data sheet for details).



For SE mode, to prevent DC currents from flowing into the speaker output coupling, capacitors are required. Output power using the SE drive is reduced by a factor of four (see the applications section in the TPA4860 data sheet for details of the tradeoffs between BTL and SE operation).

Figure 4. TPA4860 Circuit Application Connections Diagram, SE Drive

## TPA4860 Sample EVM Circuit





## 4. Specifications

**Power** 2.7 to 5.5 Vdc, 500 mA max.

**Audio Input** Mono, Cap Coupled (1.0 µF), 4 Vpp

Max @ G = 1

**Speaker Outputs** BTL 8 ohm drive, 1 W rms continuous

SE 8 ohm drive, 250 mW rms

continuous

SE 32 ohm drive, 70 mW rms

continuous

**Dummy Load Input (DL)** Recommended tie to Out- when

operating in SE mode

**Shutdown Input/Switch** High places amplifier in ultra-low

current state. Outputs are muted. Switch is a momentary action push

button. Press to mute.

HPIn1, HPIn2 Inputs High on either input places amplifier in

low current mute state.

**HP Sense Output** Logic level follows OR logic of HPIn1,

HPIn2.

**R4 Gain Control Pot** 3/4 turn adjusts amplifier gain from 2


to 20 BTL, 1 to 10 SE. Clockwise


increases gain.




## 5. Layout

**NOTE:** Layouts are not to scale.









**NOTE:** Layouts are not to scale.



## 6. Bill of Materials

Description	Ref. Desig.	PCBA Qty	Manufacturer Part Number	Digi Key Part Number
Pot., 200 K Ohm Cermet ST SL, Thru Hole	R4	1	Bourns 3323P-1-204	Digi-Key 3323P-204-ND
Cap., 10 μF/6.3 V,SMD,Size "A"	C5	1	Panasonic ECS-TOJY106R	Digi-Key PCS1106CT-ND
Cap., 1.0 µF, +80/-20%, Non- Polarized, SMD Size 1206	C2	1	Murata GRM42-6Y5V105Z16BL	Newark 93F2254
Cap., . µ F/16 V,SMD,Size 1206	C4	1	Panasonic ECS-H1CY104R	Digi-Key PCT104BCT-ND
Cap., 5.0 pF, SMD, SIZE 0805	C6	1	Panasonic ECU-V1H050CCN	Digi-Key PCC050CNCT-ND
Cap., 2.2 µF,20%, Non- Polarized, SMD Size 1206	C1,C3	2	TDK C3216X5R1A225	
Res., 20 K Ohm, 1/8 W, 5%, SMD, Size 1206	R1, R2, R3	3	Panasonic ERJ-8GEYJ203	Digi-Key P20KECT-ND
Res., 510 Ohm, 1/8 W, SMD, Size 1206	R5	1	Panasonic ERJ-8GEYJ511	Digi-Key P510ECT-ND
Switch, Momentary, SMD	S1	1	Panasonic P8048SCT-ND	Digi-Key P8048SCT-ND
IC., TPA4860, Audio Amplifier, ½ W, Mono,SMD, SOIC-8	U1	0	TI TPA4860	
PCB, TPA4680 Sample EVM	PCB1	1	Compuroute Tool # 007696	