



The RapidSE Development board provides developers with a selection of convenient interfaces to a RapidSE ZigBee Smart Energy module.

The Development board offers the same functionality as the RapidSE USB stick in connection with a PC running RapidSE Desktop, as well as UART and SPI connectivity for integration directly with third party hardware.

## Power

Both USB and an alternative user-provided DC connection are available. To use the alternate connection the shorting jumper on JP1 must be moved to pins 2&3. Shorting pins 1&2 will source power from USB. The onboard regulator is used to convert either USB provided 5V or user provided power, to 3.3V.

### USB Connection

5V up to 250mA

### Alternate Power Connector (J6 - See I/O section)

Recommended DC Power Source  
4-5VDC 250mA

### Absolute Max Input Voltage

6.5VDC (Note: Higher voltage levels will result in damage to the unit).

## LEDs

Three LED indicators are provided:

**TX** – Flashes when the module transmits serial data

**RX** – Flashes when the module receives serial data

**PWR** – Lights when there is 3V power present on the board

## Connectivity

JP2 & JP3 jumper installed on pins 1-2

*Normal USB operation*

JP2 & JP3 jumper installed on pins 2-3

*External TTL UART enabled on connector J4, USB disabled*

## I/O

### J1 – Ember SIF Connection

If using the SIF connection on the Ember InSight Adapter (ISA), the "RCM Power Select" switch on the ISA must be set to "Int" to detect the RSE.USB.DEV.2.0. The Ember InSight USB Link adapter is not currently supported. Please contact us if you require USB Link support.

### J2 – mini-B USB Connector

Installed = Bootloader mode enabled

### J4 – EM250 UART (3V) Connection

Pin 1 = GPIO 9 (module TX)  
Pin 2 = GPIO 10 (module RX)  
Pin 3 = GND

### J5 – EM250 Master SPI Port

Pin 1 = GPIO 9 (MOSI)  
Pin 2 = GPIO 10 (MISO)  
Pin 3 = GPIO 11 (CLK)  
Pin 4 = GPIO 3 (Select)  
Pin 5 = GND

### J6 – Alternate Power Connection

Pin 1 = Vin  
Pin 2 = GND  
*See Power Section*

### J9 - CTS / RTS connector

Pin 1 = CTS (USB transceiver TTL input)  
Pin 2 = RTS (USB transceiver TTL output)

### J7 & J10 – EM250 GPIO

J10 Pin 1 = GPIO 0	J7 pin 12 = GPIO 11
J10 Pin 2 = GPIO 2	J7 pin 13 = GPIO 12
J7 Pin 1 = GND	J7 pin 14 = GPIO 13
J7 Pin 2 = GPIO 1	J7 pin 15 = GPIO 14
J7 pin 3 = GND	J7 pin 16 = GPIO 15
J7 pin 4 = GPIO 3	J7 pin 17 = GPIO 16
J7 pin 5 = GPIO 4	J7 pin 18 = NRESET
J7 pin 6 = GPIO 5	J7 pin 19 = SIF MOSI
J7 pin 7 = GPIO 6	J7 pin 20 = SIF LOADB
J7 pin 8 = GPIO 7	J7 pin 21 = SIF MISO
J7 pin 9 = GPIO 8	J7 pin 22 = SIF CLK
J7 pin 10 = GPIO 9	J7 pin 23 = GND
J7 pin 11 = GPIO 10	J7 pin 24 = +3.3v