#### TEXAS INSTRUMENTS

### bq24022EVM

1-A Single-Chip Li-Ion and Li-Pol Charge Management IC with Autonomous USB-Port and AC-Adapter Supply Management Evaluation Module

## User's Guide

#### **EVM IMPORTANT NOTICE**

Texas Instruments (TI) provides the enclosed product(s) under the following conditions:

This evaluation kit being sold by TI is intended for use for **ENGINEERING DEVELOPMENT OR EVALUATION PURPOSES ONLY** and is not considered by TI to be fit for commercial use. As such, the goods being provided may not be complete in terms of required design-, marketing-, and/or manufacturing-related protective considerations, including product safety measures typically found in the end product incorporating the goods. As a prototype, this product does not fall within the scope of the European Union directive on electromagnetic compatibility and therefore may not meet the technical requirements of the directive.

Should this evaluation kit not meet the specifications indicated in the EVM User's Guide, the kit may be returned within 30 days from the date of delivery for a full refund. THE FOREGOING WARRANTY IS THE EXCLUSIVE WARRANTY MADE BY SELLER TO BUYER AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESSED, IMPLIED, OR STATUTORY, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.

The user assumes all responsibility and liability for proper and safe handling of the goods. Further, the user indemnifies TI from all claims arising from the handling or use of the goods. Please be aware that the products received may not be regulatory compliant or agency certified (FCC, UL, CE, etc.). Due to the open construction of the product, it is the user's responsibility to take any and all appropriate precautions with regard to electrostatic discharge.

EXCEPT TO THE EXTENT OF THE INDEMNITY SET FORTH ABOVE, NEITHER PARTY SHALL BE LIABLE TO THE OTHER FOR ANY INDIRECT, SPECIAL, INCIDENTAL, OR CONSEQUENTIAL DAMAGES.

TI currently deals with a variety of customers for products, and therefore our arrangement with the user **is not exclusive**.

TI assumes no liability for applications assistance, customer product design, software performance, or infringement of patents or services described herein.

Please read the EVM User's Guide and, specifically, the EVM Warnings and Restrictions notice in the EVM User's Guide prior to handling the product. This notice contains important safety information about temperatures and voltages. For further safety concerns, please contact the TI application engineer.

Persons handling the product must have electronics training and observe good laboratory practice standards.

No license is granted under any patent right or other intellectual property right of TI covering or relating to any machine, process, or combination in which such TI products or services might be or are used.

Mailing Address:

Texas Instruments Post Office Box 655303 Dallas, Texas 75265

Copyright © 2003, Texas Instruments Incorporated

#### DYNAMIC WARNINGS AND RESTRICTIONS

It is important to operate this EVM within the input voltage range of V<sub>REG</sub> + 0.5 to 5.2 V and the output range of 0 V to 4.2 V.

Exceeding the specified input range may cause unexpected operation and/or irreversible damage to the EVM. If there are questions concerning the input range, please contact a TI field representative prior to connecting the input power.

Applying loads outside of the specified output range may result in unintended operation and/or possible permanent damage to the EVM. Please consult the EVM User's Guide prior to connecting any load to the EVM output. If there is uncertainty as to the load specification, please contact a TI field representative.

During normal operation, some circuit components may have case temperatures greater than 70°C. The EVM is designed to operate properly with certain components above 70°C as long as the input and output ranges are maintained. These components include but are not limited to linear regulators, switching transistors, pass transistors, and current sense resistors. These types of devices can be identified using the EVM schematic located in the EVM User's Guide. When placing measurement probes near these devices during operation, please be aware that these devices may be very warm to the touch.

Mailing Address:

Texas Instruments Post Office Box 655303 Dallas, Texas 75265

Copyright © 2003, Texas Instruments Incorporated

#### bq24022 (bqTINY<sup>™</sup>-II) Evaluation Module

Portable Power

#### Contents

1	Introduction	. 4
2	Test Summary	. 5
3	Schematic	. 9
4	Physical Layouts	10
5	List of Materials	12
6	References	12

#### 1 Introduction

This user's guide describes the bq24022 (bqTINY<sup>™</sup>-II) Evaluation Module. The EVM provides a convenient method for evaluating the performance of a charge management solution for portable applications using the bq24022 product family. A complete designed and tested charger is presented. The charger is designed to deliver up to 1.0 A of continuous charge current for single-cell Li-Ion or Li-Pol applications using a DC power supply. The charger is programmed from the factor to deliver 0.7-A of charging current.

#### 1.1 Background

The bqTINY<sup>™</sup>-II series are highly integrated and flexible Li-Ion linear charge and system power management devices targeted at space limited charger applications. The bqTINY-II series offer integrated USB-port and ac-adapter supply management with autonomous power-source selection, power FET and current sensor, high-accuracy current and voltage regulation, charge status, and charge termination, in a single monolithic device. The bqTINY-II automatically selects the USB-port or the ac-adapter as the power source for the system. In the USB configuration, the host can select from the two preset charge rates of 100 mA and 500 mA. In the ac-adapter configuration an external resistor sets the magnitude of the system or charge current. The bqTINY-II charges the battery in three phases: conditioning, constant current, and constant voltage. Charge is terminated based on minimum current. An internal charge timer provides a backup safety for charge termination. The bqTINY-II automatically restarts the charge if the battery voltage falls below an internal threshold. The bqTINY-II automatically enters sleep mode when both supplies are removed.

#### 1.2 Performance Specification Summary

SPECIFICATION	TEST CONDITIONS	MIN	ΤΥΡ	MAX	UNIT
Input DC voltage, VI(DC)		V <sub>REG</sub> + 0.5	5.0	5.2	V
Battery charge current <sup>(1)</sup> , IO(CHG)			0.7	1.0	А
Power dissipation	$I_{CHG} \times (V_{(DC+)} - V_{(BAT+)})$			1.5	W

Table 1. Performance Specification Summary<sup>(1)</sup>

(1) This input voltage maximum is a function of the maximum allowable power dissipation on the device. The current level is programmed for 0.7 A. If the programmed charge is changed, then the maximum input voltage needs to be adjusted.  $P_{MAX(IC)} = 1.5 W = I_{CHG} (V_{(DC+)} - V_{(BAT+)})$ . The device has a maximum recommended operation of 6.5 VDC.

#### 2 Test Summary

This section shows the test setups used, and the tests performed, in evaluating the EVM. See the bq24020 datasheet (SLUS549) for complete details regarding the operation and specifications.

#### 2.1 Test Setup

The bq24022 EVM board requires a regulated 5-VDC, 1-A power source or a USB, 0.5-A port maximum), to provide input power and a single-cell Li-Ion or Li-Pol battery pack.

**NOTE:** If powered from an USB, 0.1-A port, make sure ISET2 is pulled low to program the board for the 100mA charge. Skip any test steps that program the UUT to 0.5 A.

The test setup connections and jumper setting selections are configured for a stand-alone evaluation but can be changed to interface with external hardware such as a microcontroller.

JACK	CONNECTION		
J1–DC+	Power supply positive connection, preset to 5.0VDC, 1.2–A current limit. Can also be powered by J2 (USB) if J1 power is absent.		
J1–DC–	Power supply return connection, ground		
J2–USB plug	USB 0.5-A port – source for charging when J1 source is absent		
J5–BAT+	Positive battery pack terminal		
J5–BAT–	Negative battery pack terminal, BAT- is common with DC-		
J5–CE	NC – R4 is a pull down resistor, set to 20 k $\Omega$ , to enable charging. J5– $\overline{CE}$ can be used as an external control.		
J5–BAT–	N/C, optional external use		
J3 (jumper)	ISET2 program – 0.5A (HIGH)   0.1 A (LOW)		
J4 (jumper)	Power good Indication location – LED (EVM)   EXT		
J6 (jumper)	BIAS power for EVM (jumper to active source) – DC+   USB		
J7 (jumper)	STAT1 indication location – LED (EVM)   EXT		
J9 (jumper)	STAT2 indication location – LED (EVM)   EXT		
J8–STAT1	External monitor hardware if J7–EXT is jumpered (not jumpered from factory)		
J8–STAT2	External monitor hardware if J9–EXT is jumpered (not jumpered from factory)		
J10 – PG	External monitor hardware if J4–EXT is jumpered (not jumpered from factory)		
J10–ISET2	External USB load control (TTL) – HIGH (500 mA)   LOW (100 mA) (remove jumper J3 when using J10–ISET2. EVM set up for local control with jumper J3–0.1 A installed.		

#### Table 2. I/O and Jumper Connections(1)

(1) Factory jumper selections are shown in **BOLD** 



#### 2.2 Test Procedure

Setup the evaluation board as described above, by making the necessary I/O connections and jumper selections. Prior to test and evaluation, it is important to verify that the maximum power dissipation on the device is not exceeded:  $P_{MAX} = 1.5$  W.

$$P_{MAX} = \left(V_{(DC+)} - V_{(BAT+)}\right) \times I_{(CHG)}$$
(1)

- 1. Turn on the power supply, which is preset to 5.0 VDC, and 1.0 A for the current limit setting.
- 2. The bq24022 enters preconditioning mode if the battery is below the V<sub>(LOWV)</sub> threshold. In this mode, the bq24022 precharges the battery with a low current, typically

$$\frac{I_{O(CHG)}}{10} = \frac{0.7 \text{ A}}{10} = 70 \text{ mA}$$
(2)

until the battery voltage reaches the  $V_{(LOWV)}$  threshold or until the precharge timer expires. If the timer expires then the charge current is terminated and the bq24022 enters fault mode. Both LEDs turn off when in fault mode. Toggling input power or battery replacement resets fault mode. Note that there are several fault conditions. They are described in the datasheet (SLUS549).

- Once the battery voltage is above the V<sub>(LOWV)</sub> threshold, the battery enters fast charge mode. This EVM is programmed for 0.7 A of fast charging current.
- 4. Once the battery reaches voltage regulation (4.2 V) the current tapers down as the battery reaches its full capacity.
- 5. When the current reaches the taper termination threshold, the taper timer is set and allows approximately 30 minutes of additional charging time. If the charge current increases above the taper threshold for any reason, the taper timer is reset. If the current drops below the termination threshold (design for detecting removal of battery) charging immediately terminates.
- 6. After termination, if the battery discharges down to the recharge threshold, the charger starts fast charging.
- 7. The same procedure may be performed using the USB 0.5-A plug source in place of the J1 power source. The precharge current is approximately ten percent of the programmed fast charge. The fast charge current is either 0.1 A or 0.5 A depending on the ISET being low or high.

#### CAUTION:

If powered from an USB, 0.1-A port, make sure ISET2 is pulled low to program the board for the 100mA charge.

An alternative method of testing the EVM is with a source meter, that can sink or source current. This can easily be adjusted to test each mode, in place of a battery.

Another alternative to briefly view each mode, on a scope, is to connect a  $1-\mu F$  or larger capacitor and a parallel  $10-k\Omega$  resistor on the output in place of a battery to observe the charging cycling.

#### 2.3 Alternative Test Procedure

Below is a test procedure to verify charging states without the need for a battery or expensive test equipment.

#### 2.3.1 Equipment

The procedure used to evaluate the EVM operation and the basic functions of the device is as follows:

- 1. Power source: current limited 5-V lab supply with its current limit set to 1.0 A  $\pm$ 0.1 A
- 2. Two fluke 75, equivalent or better.
- 3. Load test board as shown in Figure 1.



NOTE: R5, R6 and R7 5% or better. All other resistors 1% or better.

Figure 1. bq24022EVM Testing Setup

#### 2.3.2 Equipment Setup

- 1. Connect the load board to the BAT+ and BAT-. Set switches SW1 and SW3 to closed and switch SW2 to off (center).
- Connect a voltage meter, DMM1, to the BAT+/BAT- output to monitor the output voltage (range is 0 V to 5 V).
- Set the lab supply for 5.1 V ±0.1 VDC, 1.0 A ±0.1 A current limit and then turn off supply. Connect DMM2 across R8 to monitor the current (R8 should be a 1% or better resistor if it is used for current measurements).
- 4. Shunt jumpers should be installed on J6–DC+, J7–LED, J9–LED, J3–0.5, and J4–LED.

#### CAUTION:

If USB port is a low power port (0.1 A) and the charger is set up to draw 0.5 A, then problems or damage to the USB circuitry may occur. Therefore, when powering from a 0.1-A port, one should set J3 to 0.1 A and replace steps 7.8 through 7.11 with the following: Turn off J1 power source, set jumper to J6–USB, SW2–off, and close switches SW1 and SW3. Plug in USB power source, verify output voltage, BAT+, regulates between 2.5 and 2.9  $V_{DC}$  and both LEDs are lit. Open switch SW1 and verify output voltage, VBAT+, regulates between 4.160 and 4.240  $V_{DC}$ .

#### 2.3.3 Procedure

- 1. Make sure the steps described in *Section 2.3.2 Equipment Setup* are followed (SW1 and SW3 are set to closed, and SW2 is set to off, shunts installed as listed in step 4, test board connected, and power source set to 5.1 V  $\pm$  0.1 V<sub>DC</sub>). Turn on the power source.
- 2. Verify that output voltage, BAT+, is between 2.5  $V_{DC}$  and 2.9  $V_{DC}$  and the red LED (D1) and green LEDs (D2 and D3) are illuminated.
- 3. Momentarily short J5–2 to J1–1 ( $\overline{CE}$  to DC+) and verify that charging stops (DMM2 < 0.5mV). Remove short and verify output voltage, BAT+, is between 2.5 V<sub>DC</sub> and 2.9 V<sub>DC</sub>.
- 4. Open switch SW1. Verify LED (D2) is off and the output voltage, BAT+, regulates between  $4.160 \text{ V}_{DC}$  and  $4.240 \text{ V}_{DC}$ .
- 5. Close switch SW2 (to position 1) and verify output voltage, BAT+, is between 3.4 V<sub>DC</sub> and 3.8 V<sub>DC</sub>.
- Verify that the charging current is between 0.6 A and 0.8 A (DMM2 is between 60mVDC and 80mV<sub>DC</sub>).
- 7. Open switch SW3, set switch SW2 to off and verify that the LEDs, D1 and D2, alternate being illuminated.
- Turn off J1 power source, set jumper to J6–USB, SW2–off, and close switches SW1 and SW3. Plug in USB power source, verify output voltage, BAT+, regulates between 2.5 V<sub>DC</sub> and 2.9 V<sub>DC</sub> and both LEDs (D1, D2) are illuminated.
- 9. Open and close switch SW1, verify output voltage, VBAT+, regulates between 4.160  $V_{DC}$  and 4.240  $V_{DC}$  and LED (D2) is off.
- 10. Open switch SW1, close switch SW2 (to position 2) and verify output voltage, VBAT+, regulates between 3.1  $V_{DC}$  and 3.5 v.
- 11. Set switch SW2 to off and set jumper to J3–0.1. Verify output voltage, VBAT+, regulates between  $4.160 \text{ V}_{DC}$  and  $4.240 \text{ V}_{DC}$ .
- 12. Close switch SW1 and verify VBAT+ output is between 3.1 V<sub>DC</sub> and 3.5 V<sub>DC</sub>.
- 13. Verify that the charge current is between 0.078 A and 0.105 A (7.8 mV and 10.5 mV).
- 14. Turn off power and set jumper to J6–DC+. Remove UUT from test apparatus. Repeat setup and test procedures for other untested EVMs.

#### 2.4 Ordering Information

Table 3.	Ordering	Information
----------	----------	-------------

EVM Part Number	Additional Devices	Chemistry	Pack Voltage	Capacity	
bq24022EVM	None	Li-Ion/Li-Poly	2.5 V to 4.2 V	Any	

# 3 Schematic

Figure 2 shows the schematic diagram for the bq24022EVM.



bq24022 (bqTINY™-II) Evaluation Module



#### 4 Physical Layouts

Figure 3 shows the top layer of the EVM. Figure 4 shows the bottom layer. Figure 6 shows the top assemply view.



Figure 3. bq24022EVM Top Layer



Figure 4. bq24022EVM Bottom Layer



Figure 5. bq24022EVM Component Placement

#### 5 List of Materials

Table 4 lists the materials required for the bq24022EVM.

#### Table 4. List of Materials

REFERENCE DESIGNATOR	COUNT	DESCRIPTION	SIZE	MANUFAC	PART NUMBER
C1, C2, C3	3	Capacitor, ceramic, 1-µF, 16-V, X7R	805	Standard	Standard
D1	1	Diode, LED, red, 1.8-V, 20-mA, 20-mcd	603	Liteon	160–1181–1–ND
D2, D3	2	Diode, LED, green, 2.1-V, 20-mA, 6-mcd	603	Liteon	160–1183–1–ND
J1, J8	2	Terminal block, 2-pin, 6-A, 3.5-mm	0.27 x 0.25	OST	ED1514
J10	1	Terminal block, 3-pin, 6-A, 3.5-mm	0.41 x 0.25	OST	ED1515
J2	1	Connector, USB upstream (type B)	0.47 x 0.67	Molex	67068–1000
J3, J4, J6, J7, J9	5	Header, 3-pin, 100-mil spacing, (36-pin strip)	0.100 x 3	Sullins	PTC36SAAN
J5	1	Terminal block, 4-pin, 6-A, 3.5-mm	0.55 x 0.25	OST	ED1516
R1, R2, R6	3	Resistor, chip, 1.5-kΩ, 1/16-W, 1%	603	Standard	Standard
R3	1	Resistor, chip, 1.13-kΩ, 1/16-W, 1%	603	Standard	Standard
R4	1	Resistor, chip, 20-kΩ, 1/16-W, 1%	603	Standard	Standard
R5	1	Resistor, chip, 0-k $\Omega$ , 1/16-W, 1%	603	Standard	Standard
R7	1	Resistor, chip, 1-k $\Omega$ , 1/16-W, 1%	603	Standard	Standard
U1	1	Integrated circuit, single Li-ion, Li-poly, charge manager	MLP10	Texas Inst.	bq24022DRCR
n/a	5	Shunt, 100-mil, black	0.1	3M	929950-00
n/a	1	PCB, 2.13" × 1.25" x 0.31"	-	Any	HPA004-bq24022

#### Assembly Notes:

1. These assemblies are ESD sensitive, ESD precautions shall be observed.

2. These assemblies must be clean and free from flux and all contaminants.

3. These assemblies must comply with IPC-A-610 class 2 or better.

4. Reference designators marked with an asterisk (\*\*) cannot be substituted

5. All other components can be substituted with equivalent manufacturer's components

#### 6 References

1. Single-Chip Li-Ion and Li-Pol Charger IC with Autonomous USB-Port and AC-Adapter Supply Management (bqTINY™–II) bq24022 datasheet (SLUS549)

#### **IMPORTANT NOTICE**

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third–party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Mailing Address:

Texas Instruments Post Office Box 655303 Dallas, Texas 75265

Copyright © 2003, Texas Instruments Incorporated