

Getting started with the BelaSigna® R262 Customer Prototyping Platform



- 1 Insert two AAA batteries (not included) in the battery compartment
- 2 Move the SW1 switch to the "ON" position
- 3 Connect a pair of headphones to the AMP-OUT jack
- 4 Speak 50 cm from the microphones to evaluate "Arm's Length" mode noise reduction capabilities
- 5 Adjust the output volume with the VOL-UP and VOL-DN keys
- 6 Push the SWAP-CHAN button and speak 5 cm from the microphones to evaluate "Handset" mode

For more information go to www.onsemi.com/BR262



ON Semiconductor®